

TIO-540-AK1A Illustrated Parts Catalog

October 2026

|PC-TIO-540-AK1A Rev. 2



652 Oliver Street
Williamsport, PA 17701

TIO-540-AK1A Illustrated Parts Catalog

| Lycoming Part Number: PC TIO-540-AK1A Rev. 2

For additional information:

Mailing address:

Lycoming Engines
652 Oliver Street
Williamsport, PA 17701 U.S.A.

Phone:

Product Support: U.S. and Canada toll free: +1-877-839-7878
International Customers: +1-570-323-7222

Lycoming Product Support regular business hours are:

Monday through Thursday from 8:00 A.M. through 10:00 P.M. Eastern Time (-5 GMT)

Friday from 8:00 A.M. through 6:00 P.M. Eastern Time (-5 GMT)

or Email: Technicalsupport@lycoming.com

Visit us online at:

www.lycoming.com



©2026 Lycoming. All Rights Reserved.

Lycoming and "Powered by Lycoming" are trademarks or registered trademarks of Lycoming.

Lycoming Engines, a division of AVCO Corporation.

All brand and product names referenced in this publication are trademarks or registered trademarks of their respective companies.

Record of Revisions

NOTICE: Service Documents with a later release date than this parts catalog override parts information in this document.

Rev No.	Revision Changes	Issue Date
New	Initial Release of PC-TIO-540-AK1A (Supersedes PC-315-13)	June 2025
Rev. 1	Chapter 72-40 - Replaced P/N 72376 with P/N 72376-CT in the parts list for Figure 14A - Replaced P/N 72376 with P/N 72376-CT in the parts list for Figure 14B - Revised the part number and description for Item 14 in the parts list for Figure 14B - Added footnotes for Items 1, 12, and 20 Crankshaft and Counterweight Assembly Kit - Changed the kit P/N from 05K47793 to 05K47677 - Revised the parts list for the kit - Changed crankshaft assembly P/N from 13F47743 to 13E47622 - Changed dynamic counterweight roller P/N from 73648 to LW-15558	March 2026
Rev. 2	Table of Contents - Revised page numbers beginning with Chapter 74-20 and following Chapter 72-30 - Corrected footer heading to 72-30 from 72-40 Chapter 73-10 - Revised Figure 24 by removing Nozzle Assembly part 10 from figure and renumbering part 15 to part 10 Nozzle Assembly Seal & Gasket Kit - Change part number to 05K23204. Chapter 74-20 - Revised Figure 27 and added P/N MS20822-4 elbow - Revised Figure 27 parts list by increasing P/N MS20822-4 elbow quantity to 2 Chapter 72-50 - Revised Figure 14A and Figure 14A parts list by removing P/Ns MS29512-04 and AN814-4L. Added a ghost image of the magneto pressurization adapter assembly to Figure 14A. - Revised Figure 14B and Figure 14B parts list by removing P/Ns MS29512-04 and AN814-4L. Added a ghost image of the magneto pressurization adapter assembly to Figure 14B. - Revised Figure 15 and Figure 15 parts list by adding P/Ns MS29512-04 and AN814-4L	October 2026

This page intentionally left blank.

Table of Contents

<u>Subject</u>	<u>Chapter - Section</u>	<u>Page</u>
Frontal		
Record of Revisions		iii
Table of Contents		v
Introduction		vii
Abbreviations and Acronyms		xi
Oversize and Undersize Part Listing		xiii
Electrical Power	24-00	
AC Generation	24-20	
1. Alternator Mounting and Attaching Parts		0-1
Reciprocating Engine	72-00	
Front Section	72-10	
1. Propeller Governor Drive Assembly		2-3
Power Section	72-20	
1. Crankcase Assembly		4-5
2. Crankcase Related Parts		6-7
3. Crankshaft, Counterweight, Camshaft, and Related Parts		8-9
4. Crankshaft and Fuel Pump Idler Gears		10-11
5. Crankcase Attaching Parts		12-13
Cylinder Section	72-30	
1. Connecting Rods, Pistons, and Ring Assemblies		14-15
2. Cylinder Assembly		16-17
3. Valve Assembly and Related Parts		18-19
3. Cylinder Related Parts		20-21
Turbocharger System	72-40	
1. Turbocharger, Brackets, and Attaching Parts		22-23
2. Turbo Oil Drain Tank, Hoses, and Attaching Parts		24-25
3. Sloped Controller and Related Parts		26-27
Lubrication System	72-50	
1. Intake Pipes, Air Inlet Housing, and Attaching Parts		28-29
2. Oil Level Gage Assembly and Engine Mounting Brackets		30-33
3. Oil Sump Assembly, Induction Housing, and Oil Suction Screen		34-35

<u>Subject</u>	<u>Chapter - Section</u>	<u>Page</u>
Accessory Drives	72-60	
1. Accessory Housing Assembly.....		36-37
2. Oil Pump Assembly and Accessory Housing Attaching Parts		38-39
3. Fuel Pump Assembly and Attaching Parts		40-41
4. Hydraulic Pump Drive and Cover.....		42-43
5. Turbo Scavenge Pump and Vacuum Pump Drive and Cover.....		44-45
6. Oil Filter Assembly, Oil Cooler Bypass Valve, and Breather Fitting.....		46-47
Engine and Fuel Control	73-00	
Fuel Distribution	73-10	
1. Fuel Injector, Fuel Manifold, and Injection Nozzles		48-49
2. Fuel Lines and Attaching Parts		50-51
3. Injector Nozzle Vent Manifolds, Hoses and Attachments		52-53
Ignition Distribution System	74-00	
Ignition Distribution	74-20	
1. Magnetos, Magneto Drives, Harnesses, and Spark Plugs		54-59
Exhaust System	78-00	
1. Exhaust Pipes and Transition Assembly		60-61
Starting	80-00	
Cranking	80-10	
1. Starter Assembly and Attaching Parts		62-64
Back Section		
Service Kit Section		65-67
Numerical Index		68-76

Introduction



CAUTION:

DO NOT USE THIS CATALOG AS AN ASSEMBLY OR INSTALLATION DOCUMENT. THIS CATALOG MUST ONLY BE USED TO IDENTIFY PARTS IN CONJUNCTION WITH THE APPLICABLE MAINTENANCE OR OVERHAUL MANUAL.

PART NUMBERS AND DESCRIPTIONS IN THIS PARTS CATALOG ARE NOT
AUTHORITATIVE AND CAN BE SUPERSEDED BY FAA APPROVED SERVICE
BULLETINS AND SERVICE INSTRUCTIONS.

Purpose of this Catalog

This Illustrated Parts Catalog (IPC) contains a complete list of spare parts for the Lycoming TIO-540-AK1A engine model.

How to Use this Catalog

This catalog is based on the Air Transport Association (ATA) Spec 100 format. To clarify illustrations, Lycoming has taken discretion to classify non-system related assemblies and components in the same chapters, because they are physically connected.

This catalog is frequently updated by Service Bulletins (SB) and Service Instructions (SI). The updated information will be incorporated into subsequent full revisions of this catalog.

The ATA two-element numbering system provides consistency throughout various manuals. The bottom of each page (beyond the frontal section) contains a two-element number (##-##). In the two-element numbering, the first two digits represent a chapter, and the next two digits subdivide the material into a more specific section.

The ATA format specifies the subject matter for each chapter-section. According to the ATA Standards, the following chapters apply to the TIO-540-AK1A Illustrated Parts Catalog:

24 (Electrical Power), 72 (Reciprocating Engine), 73 (Engine and Fuel Control), 74 (Ignition), and 80 (Starting).

EXAMPLE: **74** **—** **20**
Chapter Section
Ignition **Distribution**

NOTICE: Refer to the IPC Table of Contents for the subsystems identified in each section.

Numerical Index

The Numerical Index is a single list of part numbers, names and their locations within the IPC. It is useful for locating parts when you only know the number or name of the part.

Description column

Indentation of a part name represents a lower level of assembly. Attaching parts have the same indentation level and are below their associated parts grouping or assembly. This column is often referred to as the "Nomenclature" on other ATA Spec manuals.

Units per Assembly Column

Where more than one assembly exists, this column contains the quantity of a specific part required in the build sequence of only one next higher assembly. The letters “AR” are for “as required” applicable to bulk items or non-illustrated select-from-range-parts. The letters “RF” identify items for reference.

Lockwire, Safety Cable

To maintain as assembled torque integrity Lockwire used is to be a one continuous strand twisted to keep tension on various internal fasteners ensuring a minimum torque is retained. Lockwire installed correctly will pull in the direction of fastener assembled tension. Lycoming Engines does not recommend the use of safety cable for retention of internal engine parts or assemblies. Refer to the latest revision of **Service Instruction No. 1566**.

Vendor Accessories

Parts coverage of Vendor Accessories used on Lycoming engines are found in the applicable Vendor's Parts Catalog. A list of vendors' addresses is included in the latest revision of Lycoming Service Letter No. L114.


Any reference in this document to the suppliers/part manufacturer's product, by name, trademark, part number or other description is solely for the purpose of identification and does not indicate or infer that Lycoming accepts responsibility for quality control and/or airworthiness of parts, which do not pass through the Lycoming quality control system.

Environmental Compliance

Lycoming is concerned with preserving the environment. Lycoming strongly urges engine owners and repair/overhaul personnel to observe and comply with all federal, state, and local environmental regulations when solvents, paint, fuel, oil, chemicals, or other consumables are used in operating, maintaining, or overhauling an engine component. Please share our concern for and commitment to a clean earth, clean water, and especially clean air for succeeding generations of flyers.

Perspective of References

In this manual, all references to locations of various components will be designated as if viewing the engine from the rear (or anti-propeller) end. The front of the engine is the propeller end and the oil sump is on the bottom of the engine. Cylinders are numbered from front to rear with the odd-numbered cylinders on the right-hand side. The firing order for this engine is 1-4-5-2-3-6.



Top View of Engine

How to Order Parts

To order parts from this parts catalog, contact an Authorized Lycoming Distributor with the part number(s), nomenclature, and quantity along with the model and serial number of your engine. Authorized Lycoming Distributors will have up-to-date part number supersedure, pricing, and availability information on parts listed in this parts catalog.

An Oversize and Undersize Parts List is included in the front section of this catalog to aid in ordering parts as necessary during maintenance or overhaul.

To supply any comments, suggestions, or corrections to this parts catalog, go online to the Lycoming.com website on the internet.

NOTE:

Lycoming recommends that owners of this manual sign up for email notification on the Technical Publications page of our website <https://www.lycoming.com/contact/knowledge-base/publications>. By submitting your email address, you will receive notification whenever Lycoming publishes a new or revised technical publication, including any revisions to this parts catalog.

©2026 by Lycoming. "All Rights Reserved." All Lycoming publications are to be considered copyrighted and may not be reproduced without permission of the company.

Abbreviations and Acronyms

A	
AR	As Required
Assy.	Assembly
ATA	Air Transport Association
C	
Cyl.	Cylinder
D	
dia.	Diameter
F	
Fill.	Fillister
H	
Hex.	Hexagon
I	
I.D.	Inside Diameter
in.	Inch
IPC	Illustrated Parts Catalog
N	
No.	Number
NPT	National Pipe Thread
O	
O.D.	Outside Diameter
P	
P	Lycoming Proprietary Part
P/N	Part Number
R	
RF	Reference
S	
SB	Service Bulletin
SI	Service Instruction
SSP	Special Service Publication
U	
UNF	Unified National Fine



This page intentionally left blank.

Oversize and Undersize Parts Listing

PART NO.	DESCRIPTION	OVERSIZE (IN.)			UNDERSIZE (IN.)	
		P05 .005	P10 .010	P50 .050	M03 .003	M06 .006
66670	BUSHING	X	X			
61681	GUIDE	X	X			
66796	INSERT	X	X			
69796	DOWEL	X				
72155-S	BUSHING	X	X			
73810	BUSHING	X				
75656-S	BUSHING	X	X			
75657-S	BUSHING	X	X			
16R22291	GUIDE	X	X			
LW-11997	SEAL			X		
LW-12688	SEAT		X			
18M26105	BEARING				X	X
LW-13792	SEAL			X		
STD-1065	DOWEL	X				
16T19468	SEAT		X			
18A26093	BEARING				X	X
18D26098	BEARING				X	X

NOTICE:

When ordering oversize and undersize parts, be sure to specify the required oversize and undersize dimension along with the proper part number. For example, to order bearing P/N 18D26098 bearing in 0.003 in. undersize, order P/N 18D26098-M03. Undersize code letter is "M" while oversize code letter is "P". These letters are then followed by the number designating the size in thousandths of an inch.




Figure 1
Alternator Mounting and Attaching Parts

Figure 1 - Alternator Mounting and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		07A21443	BRACKET, Alternator	1
2		73383	LOCKPLATE, 5/16 bolt x 1.00 spacing	1
3		LW-31-0.94	BOLT, 5/16-18 x 15/16 long, hex. head	2
4		STD-35	WASHER, 5/16 plain	1
5		LW-31H0.88	BOLT, 5/16-18 x 7/8 long, hex head, drilled	1
6		76908	STRUT, Alternator support	1
7		LW-31H0.88	BOLT, 5/16-18 x 7/8 long, hex head, drilled	1




Figure 2
Propeller Governor Drive Assembly

Figure 2 – Propeller Governor Drive Assembly

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-10442	GEAR, Propeller governor driven	1
2		LW-14021	SHAFT, Propeller governor idler gear	1
3		LW-10541	GEAR ASSEMBLY, Propeller governor idler	1
4		77872	BUSHING, Propeller governor idler gear	2
5		STD-19	DOWEL, 3/32 diameter x 7/32 long	1
6		STD-798	DOWEL, 3/32 diameter x 9/32 long	1
7		73249	WASHER, Thrust (0.0585 - 0.0595 thick)	AR
		73250	WASHER, Thrust (0.062 - 0.063 thick)	AR
		73251	WASHER, Thrust (0.0655 - 0.0665 thick)	AR
		73252	WASHER, Thrust (0.069 - 0.070 thick)	AR
		01L21418	WASHER, Thrust (0.055 - 0.056 thick)	AR
8		AN565B1032H5	SET SCREW, No.10-32 x 1/32 long	1
9		70455	GASKET, 25/32 I.D. x 1-1/8 O.D. x 1/32 thick	1
10		LW-13896	PLUG, 0.750-16 hex head	1
11		72053	GASKET, Governor	1
12		72378	COVER, Governor drive	1
13		STD-35	WASHER, 5/16 plain	4
14		STD-475	WASHER, 5/16 lock, internal teeth	4
15		STD-1410	NUT, 5/16-18 plain	4
AR as required				




Figure 3
Crankcase Assembly

Figure 3 - Crankcase Assembly

Figure Item	Code	Part Number	Description	Units per Assembly
1		11E24105-S1-S	CRANKCASE ASSEMBLY KIT (roller tappet)	1
	P	11E24105-S1	CRANKCASE ASSEMBLY (roller tappet)	1
		11E24005-S1	CRANKCASE ASSEMBLY KIT (flat tappet)	
	P	11E24005-S	CRANKCASE ASSEMBLY (flat tappet)	
2		STD-1339	PLUG, 1/16-27 NPT	1
3		1102	PLUG, 1/8 pipe	4
4		31C-17	STUD, 5/16-18 x 2-1/8 long	4
5		73772	NOZZLE ASSEMBLY, Piston cooling	6
6		MS29512-06	O-RING, 15/32 I.D. x 5/64 section	1
7		AN814-6L	PLUG, 9/16-18 hex. head	1
8	*	75739-CT	NIPPLE, 3/8 flared tube	1
P Lycoming proprietary part. Listed for reference purposes only, cannot be purchased * Uses a P/N MS29512-06 O-ring.				




Figure 4
Crankcase Related Parts

Figure 4 - Crankcase Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		1028-B	BALL, 11/16 diameter	1
2	*	61084	SPRING, Oil pressure relief valve	1
	*	68668	SPRING, Oil pressure relief valve	1
	*	77467	SPRING, Oil pressure relief valve	1
	*	LW-11713	SPRING, Oil pressure relief valve	1
	*	LW-18085	SPRING, Oil pressure relief valve	1
3		06E19769-1.25	GASKET, Annular, 1-1/4 I.D.	1
4		77808	VALVE ASSEMBLY, Oil pressure relief	1
5		76159	PLUG, Oil relief valve	1
6		76162	INSERT, Oil pressure relief valve	1
7		76161	CAP, Oil pressure relief valve	1
8		77807	SCREW, Oil pressure adjusting	1
9		AN310-6	NUT, 3/8-24 NF-3 (castellated)	1
10		MS171526	PIN SPRING, 1/8 diameter x 1/2 long	1
11		18D26098	BEARING, Crankshaft	6
12		18A26093	BEARING, Crankshaft	2
13		LW-13792	SEAL, Crankshaft, oil	1
14		72091	RING, Oil seal, 23/64 I.D. x 1/10 diameter	2
15		15B26588	BODY, Hydraulic, spherical, tappet	12
16		LRT23381	BODY, Hydraulic tappet, roller type	12
* Select the spring to give a minimum of three threads exposed, on adjusting screw, to allow field adjustment. Refer to the latest revision of SSP-1776, Part I for spring identification.				




Figure 5
Crankshaft, Counterweight, Camshaft, and Related Parts

Figure 5 - Crankshaft, Counterweight, Camshaft, and Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		13E47622	CRANKSHAFT ASSEMBLY	1
2		71640	PLUG, 1.38 diameter expansion	1
3		68484	TUBE, Crankshaft propeller, oil	1
4		75656-S	BUSHING, Propeller flange, long	4
5		72155-S	BUSHING, Propeller flange, 0.7505-0.7510	1
6		75657-S	BUSHING, Propeller flange, 0.7818-0.7823	1
7	*	LW-19210	COUNTERWEIGHT ASSEMBLY	2
8		LW-19200	COUNTERWEIGHT, Dynamic	1
9	**	71903-A	BUSHING, Dynamic counterweight	4
10		LW-15558	ROLLER, Dynamic counterweight	2
11	*	76788	ROLLER, Dynamic counterweight, 6.3 order	2
12		71907	WASHER, Counterweight	8
13		LW-14820	RING, Internal retaining	8
14		STD-1211	PLUG, 2.00 diameter expansion	1
15	+	13S19648	GEAR, Crankshaft	1
16	+	LW-18638	LOCKPLATE, Crankshaft gear	1
17	+	STD-2247	BOLT, 5/16-24 x 1-3/4 long	1
18		15N23374	CAMSHAFT ASSEMBLY, (Roller lifter)	1
		LW-19340	CAMSHAFT ASSEMBLY, (Flat tappet)	1
19		15N23373	CAMSHAFT, Low speed (roller lifter)	1
		LW-13908	CAMSHAFT (flat tappet)	1
20		76118	SPACER, Tachometer shaft centering	1
21		76155	SHAFT ASSEMBLY, Tachometer	1
22		76154	SHAFT, Tachometer	1
23		60463	TUBE, Tachometer	1
24		LW-18667	PIN, 3/16 diameter x 2-1/3 long	1
25		STD-2231	RING, Internal retaining (13/16 diameter housing)	1
26		31M22993	SUPPORT ASSEMBLY, Starter ring gear	1
27		72566	GEAR, Starter ring, 12/14 pitch	1
* Refer to latest revision of Service Instruction No. 1012 for application. ** Refer to latest revision of Service Instruction No. 1143 for application. + Refer to latest revision of Service Instruction No. 475 for application.				




Figure 6
Crankshaft and Fuel Pump Idler Gears

Figure 6 - Crankshaft and Fuel Pump Idler Gears

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-13795	SHAFT, Crankshaft idler gear	2
2		LW-31H0.88	BOLT, 5/16-18 x 7/8 long, hex head, drilled	3
3		STD-2168	NUT, 5/16-18 NC, slotted, shear	1
4		72246	SHAFT, Fuel pump idler gear	1
5		71667	LOCKPLATE, 1/4 bolt x 1-3/4 spacing	1
6		LW-25-0.63	BOLT, 1/4-20 x 5/8 long, hex. head	2
7		71664	GEAR ASSEMBLY, Fuel pump idler	1
8		77309	BUSHING, Crankshaft idler gear	1
9		70474	WASHER, Fuel pump idler, thrust	1
10		STD-1737	RING, External retaining, 9/16 diameter	1
11		71668	GEAR ASSEMBLY, Crankshaft idler, plain	2
12		67530	BUSHING, Crankshaft idler gear	1
13		72972	SHAFTGEAR ASSEMBLY, Fuel pump drive	1
14		72962	THRUST BUTTON, Vacuum pump gear	1
15		69164	GASKET, Fuel pump adapter	1
16		69159	ADAPTER ASSEMBLY, Fuel pump drive	1
17		STD-1774	PIN, 1/8 diameter x 1/4 long	1
18		STD-213	OIL SEAL, 3/4 I.D. x 1-3/8 O.D.	1




Figure 7
Crankcase Attaching Parts

Figure 7 - Crankcase Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-25-1.50	BOLT, 1/4-20 x 1-1/2 long, hex. head	7
2		LW-25-1.88	BOLT, 1/4-20 x 1-7/8 long, hex. head	2
3		LW-25-2.00	BOLT, 1/4-20 x 2.00 long, hex. head	4
4		STD-8	WASHER, 1/4 plain	24
5		60803	STRAP, Lifting	2
6		LW-25-1.13	BOLT, 1/4-20 x 1-1/8 long, hex. head	1
7		73966	SPACER, Fuel manifold bracket	1
8		STD-160	WASHER, 1/4 lock, internal teeth	13
9		STD-1411	NUT, 1/4-20 plain	12
10		LW-25S1.50	BOLT, 1/4-20 x 1-1/2 long, hex. head, drilled	6
11		STD-8	WASHER, 1/4 plain	6
12		STD-2249	NUT, 1/4-20 slotted shear	6
13		STD-33	WASHER, 3/8 plain	1
14		STD-872	NUT, 3/8-24 slotted	1
15		AN6-34A	BOLT, 3/8-24 x 3-37/64 long, hex. head	1
16		STD-33	WASHER, 3/8 plain	3
17		STD-678	WASHER, 3/8 lock, internal teeth	2
18		STD-596	NUT, 3/8-24 plain	2
19		76220	STUD, 1/2-20 x 10-45/64 long	8
20		LW-31-2.75	BOLT, 5/16-18 x 2-3/4 long	1
21		LW-31-1.16	BOLT, 5-16-18 x 1-5/32 long	3
22		STD-35	WASHER, 5/16 plain	4
23		STD-475	WASHER, 5/16 lock, internal teeth	4




Figure 8
Connecting Rods, Pistons, and Ring Assemblies

Figure 8 - Connecting Rods, Pistons, and Ring Assemblies

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-11750-S	CONNECTING ROD ASSEMBLY	6
	P	LW-11750	CONNECTING ROD	6
2	P	14S23890	BOLT, Connecting rod	12
3		LW-12186	NUT, Connecting rod bolt	12
4		18M26105	BEARING, Connecting rod	12
5		14D23913	PISTON, Compression ratio 8.00:1, 5-1/8 bore,	6
6	*	LW-14078	PIN, Piston	6
7		72198	PLUG, Piston pin	12
8		74241	RING, Piston, compression, 5-1/8 bore	12
9		14H29889	RING, Piston, oil, 5-1/8 bore	6
P Lycoming proprietary part - for reference purposes only, cannot be purchased. * Refer to the latest revision of Lycoming Service Instruction No. 1267.				




Figure 9
Cylinder Assembly

Figure 9 - Cylinder Assembly

Figure Item	Code	Part Number	Description	Units per Assembly
1		16A30100-01	CYLINDER & HEAD ASSEMBLY	6
2		72057	SEAT, Intake valve	6
3		72058	SEAT, Valve, exhaust	6
4	*	16R22126	GUIDE, Exhaust valve (NI-resist)	6
5	*	76943	GUIDE, Valve, intake	6
6		69260	INSERT, Spark plug, 18-1.5 mm	12
7		STD-1353	INSERT, 10-24 UNC x 3/8 long	6
8		31C-12	STUD, 5/16-18 x 1-1/2 long	12
9		25C-8	STUD, 1/4-20 x 1.00 long	6
10		66610	BUSHING, Rocker shaft	24
11		MS20823-6D	ELBOW, 45 deg, 3/8 flared tube	6
12		1102	PLUG, 1/8 PIPE	6
13		71481	RING, Oil seal	6
* Refer to the latest revision of Lycoming Service Instruction No. 1256 for valve guides for service use.				




Figure 10
Valve Assembly and Related Parts

Figure 10 – Valve Assembly and Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		16A30100-01	CYLINDER AND HEAD ASSEMBLY, Nitrided	6
2		17A23938	VALVE, Intake	6
3		17B23936	VALVE, Exhaust (rotator type)	6
4		LW-10077	SEAT, Valve spring, upper intake	6
5		LW-16475	SEAT, Valve spring, upper exhaust (rotator type)	6
6		65441	SEAT, Valve spring, lower intake	6
7		LW-13323	SEAT, Valve spring, lower exhaust	6
8		60009	KEY, Valve, intake	12
9		17C21191	KEY, Valve, exhaust (rotator type)	12
10		17C19386	CAP, Valve stem, exhaust (rotator type)	6
11		17D29055	SPRING, Valve, inner	12
		LW-11795	SPRING, Valve, inner	12
12		17D29060	SPRING, Valve, outer	12
		LW-11800	SPRING, Valve, outer	12
13		15B26066	PLUNGER ASSEMBLY, Hydraulic tappet	12
14		15B21319	SOCKET, Push rod, hydraulic tappet	12
15		15G23461	SHROUD TUBE, Push rod (roller tappet)	12
16		LW-11485	SHROUD TUBE, Push rod (flat tappet)	12
17		01L23459	WASHER, 25/32 ID X 1 3/8 OD X 3/64	12
18		LW-14995	SPRING, Shroud tube	6
19		LW-12272	LOCKPLATE, Shroud tube	6
20		STD-1411	NUT, 1/4-20 plain	6
21		06A23493	SEAL, Shroud tube (roller tappet)	12
22		LW-18661	SEAL, Shroud tube (flat tappet)	12
23		70310	SEAL, Shroud tube	12
24	*	15F28835-28	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-29	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-30	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-31	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-32	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-33	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-34	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-35	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-36	ROD ASSEMBLY, Push (A total of 12 required)	AR
	*	15F28835-37	ROD ASSEMBLY, Push (A total of 12 required)	AR

(Continued on next page)

Figure 10 – Valve Assembly and Related Parts (Cont.)

Figure Item	Code	Part Number	Description	Units per Assembly
25	**	17F19357	ROCKER ASSEMBLY, Valve	12
26		74637	BUSHING, Valve rocker	12
27		LW-13790	SHAFT, Valve rocker	6
28		LW-12892	THRUST BUTTON, Rocker shaft	12
29		1102	PLUG, 1/8 pipe	6
AR as required * Refer to the latest revision of Service Instruction No. 1060 for complete push rod application. ** Due to the size of the area where the part number is stamped, the last five digits (19357) could be all that is shown of the part number.				

This page intentionally left blank.




Figure 11
Cylinder Related Parts

Figure 11 – Cylinder Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		STD-684	NIPPLE, Straight, 3/8 I.D. hose	6
2		STD-1821	HOSE, 3/8 x 2-1/2 long	6
3		LW-15592-5-04	CLAMP, Hose, 7/16 OD	12
4		68759	TUBE ASSEMBLY, Cyl. head oil drain, cyl. No. 1	1
5		71737	TUBE ASSEMBLY, Cyl. head oil drain, cyl. No. 2	1
6		68761	TUBE ASSEMBLY, Cyl. head oil drain, cyl. No. 3, 4, 5, 6	4
7		LW-13389	BAFFLE ASSEMBLY, Intercylinder	2
8		71611	RETAINER, Intercylinder baffle	4
9		71610	HOOK, Intercylinder baffle retainer	4
10		MS35489-20X	GROMMET	2
11	*	06B26669	GASKET, Rocker box cover (Silicone)	6
	*	75906	GASKET, Rocker box cover	6
12		61247	COVER, Rocker Box	6
13		STD-1925	SCREW, 1/4-20 x 5/8 long, pan. Head, self-locking	36
14		74494	PLATE, Spark plug reach caution	6
15		71481	RING, Oil seal, 3/32 dia. x 4-27/32 I.D.	6
16		77906	SPACER, 33/64 I.D. x 7/8 O.D. x 1/8 thick	2
17		74887	SPACER, 33/64 I.D. x 7/8 O.D. x 3/8 thick	2
18		383-B	NUT, 3/8-24 plain	24
19		STD-2090	NUT, 1/2-20 plain	28
* Refer to the latest revisions of Service Letter No. 272 and Service Instruction No. 1588 for additional information.				




Figure 12
Turbocharger, Brackets, and Attaching Parts

Figure 12 - Turbocharger, Brackets, and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		07A22810	BRACKET, Turbo mounting	1
2		STD-33	WASHER, 3/8 plain	2
3		STD-678	WASHER, 3/8 lock internal teeth	2
4		LW-38-2.75	BOLT, 3/8-16 x 2-3/4 long hex	1
5		LW-38-3.50	BOLT, 3/8-16 x 3-1/2 long hex	1
6		46C22924	TURBOCHARGER	1
7		AN960C616	WASHER, 3/8 plain	4
8		MS9321-12	WASHER, 3/8 I.D. x 3/4 O.D.	4
9		AN6C12A	BOLT, 3/8-24 UNF x 1-5/16 long	4
10		MS20500-624	NUT, 3/8-24 self-locking	4
11		LW-12960	*VALVE, Exhaust by-pass	1
12		75845	GASKET, V-band coupling, 2-1/4 tube	1
13		40D22383	COUPLING, V-band	1
14		AN960C516	WASHER, 3/8 plain	2
15		LW-31SSH0.88	BOLT, Hex head coarse thread	2

* Note that some engines are configured with the exhaust by-pass valve installed as shown in Installation A. Other engines are configured with the exhaust by-pass valve rotated 180° as shown in Installation B. Refer to parts lists for Figures 14A and 14B for changes to the hose part numbers required for each installation.




Figure 13
Turbo Oil Drain Tank, Hoses, and Attaching Parts

Figure 13 - Turbo Oil Drain Tank, Hoses, and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		MS20822-4	ELBOW, 1/8 NPT to 1/4 tube 90°	1
2		LW-12878-4S373	HOSE ASSEMBLY	1
3		LW-16266-25-63	CLAMP, 5/8 I.D. x 1/4 diameter	1
4		78212	VALVE ASSEMBLY, Check	1
5		77813	GASKET, Turbo oil inlet adapter	1
6		LW-12287	ADAPTER, Turbo oil inlet	1
7		STD-35	WASHER, 5/16 plain	2
8		STD-475	WASHER, 5/16 lock, internal teeth	2
9		LW-31-0.94	BOLT, 5/16-18 x 15/16 long, hex. head	2
10		LW-18038	GASKET, Turbo oil drain	1
11		58B22954	TANK, Turbo oil drain, right	1
12		STD-33	WASHER, 3/8 plain	2
13		STD-678	WASHER, 3/8 lock, internal teeth	2
14		LW-38-0.75	BOLT, 3/8-16 x 3/4 long, hex. head	2
15		MS20823-8	ELBOW, 1/2 flared tube, 3/8 NPT	1
16		LW-14848-8S360	HOSE ASSEMBLY, 1/2 hose, 90° elbow	1
17		LW-14685-CT	ELBOW, 1/2 tube x 3/4-16	1
18		MS20822-4	ELBOW, 1/8 NPT to 1/4 tube 90°	1
19		LW-12878-4S373	HOSE ASSEMBLY	1
20		MS20822-4	ELBOW, 1/8 NPT to 1/4 tube 90°	1
21		76734	ZIP STRAP	2
22		07A22955	BRACKET, Turbo oil drain tank	1
23		AN960C516	WASHER, 5/16 plain	1
24		STD-475	WASHER, 5/16 lock, internal teeth	1
25		LW-31SS-0.75	BOLT, 5/16-18 x 3/4 long, hex. head	1
26		STD-425	WASHER, No. 10 plain	2
27		STD-1650	BOLT, No. 10-32 x 21/32 long, hex. head	1
28		MS21042-3	NUT, Self-locking	1




Figure 14A
Sloped Controller and Related Parts

Figure 14A - Sloped Controller and Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		48B22970	CONTROLLER, Sloped	1
2		LW-12798-4S274	HOSE ASSEMBLY, 1/4 hose, straight	1
3		73152	BRACKET, Support clamp	2
4		LW-16266-10-63	CLAMP, 5/8 I.D. x No.10 screw	2
5		STD-692	SCREW, No. 10	2
6		STD-670	LOCK NUT, No. 10	2
7	*	72376-CT	ELBOW, 90°, 1/4 tube to 7/16 thread	1
8	**	72377	ELBOW, 3/8 flared tube, adjustable	1
9		LW-12877-6S161	HOSE ASSEMBLY, 3/8 hose, 90° elbow	1
10	**	75739-CT	NIPPLE, 9/16-18, 3/8 flared tube	1
11	**	74070	ELBOW, 3/8 flared tube, 9/16-18 thread	1
12		LW-12799-6S180	HOSE ASSEMBLY, 3/8 hose, straight	1
13		AN912-9	BUSHING, Reducer, 3/4 NPT	1
14		MS20823-6	ELBOW, 1/4 NPT to 3/8 flared tube	1
15	**	LW-16561	NIPPLE, 1/4 tube to 9/16-18	1
16		LW-12798-4S111	HOSE ASSEMBLY, 1/4 hose, straight	1
17	***	02G22466	NIPPLE, 5/16-24 to 7/16-20	1
18		78303	TEE, 1/4 O.D.	1
19		02G22988	NIPPLE, 1/4 flared tube to 1/8-27 NPT (Rest. 0.03)	1
20		LW-12798-4S130	HOSE ASSEMBLY, 1/4 hose, straight	1
21		LW-12798-4S303	HOSE ASSEMBLY, 1/4 hose straight	1
22	**	LW-16561	NIPPLE, 1/4 tube to 9/16-18	1
23	+	02A22992	TEE, 1/4 tube O.D. with swivel nut on one end	1
Note: Use this parts list for engines with the exhaust by-pass valve installed as shown in Figure 12, Installation A. * Uses a P/N MS29512-02 O-ring. ** Uses a P/N MS29512-04 O-ring. *** Uses a P/N MS29512-06 O-ring. + Ship loose (Cessna oil separator).				




Figure 14B
Sloped Controller and Related Parts

Figure 14B - Sloped Controller and Related Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1	●	48B22970	CONTROLLER, Sloped	1
2		LW-12798-4S370	HOSE ASSEMBLY, 1/4 hose, straight	1
3		73152	BRACKET, Support clamp	2
4		LW-16266-10-63	CLAMP, 5/8 I.D. x No.10 screw	2
5		STD-692	SCREW, No. 10	2
6		STD-670	LOCK NUT, No. 10	2
7	*	72376-CT	ELBOW, 90°, 1/4 tube to 7/16 thread	1
8	**	72377	ELBOW, 3/8 flared tube, adjustable	1
9		LW-12877-6S161	HOSE ASSEMBLY, 3/8 hose, 90° elbow	1
10	**	75739-CT	NIPPLE, 9/16-18, 3/8 flared tube	1
11	**	74070	ELBOW, 3/8 flared tube, 9/16-18 thread	1
12	■	LW-12877-6S254	HOSE ASSEMBLY, 3/8 hose, 90° elbow	1
13		AN912-9	BUSHING, Reducer, 3/4 NPT	1
14		MS20823-6	ELBOW, 1/4 NPT to 3/8 flared tube	1
15	**	LW-16561	NIPPLE, 1/4 tube to 9/16-18	1
16		LW-12798-4S370	HOSE ASSEMBLY, 1/4 hose, straight	1
17	***	02G22466	NIPPLE, 5/16-24 to 7/16-20	1
18		78303	TEE, 1/4 O.D.	1
19		02G22988	NIPPLE, 1/4 flared tube to 1/8-27 NPT (Rest. 0.03)	1
20	◆	LW-12876-4S150	HOSE ASSEMBLY, Teflon, 1/4 hose, 90° elbow with straight fitting, 15 in. long	1
21		LW-12798-4S340	HOSE ASSEMBLY, 1/4 hose straight	1
22	**	LW-16561	NIPPLE, 1/4 tube to 9/16-18	1
23	+	02A22992	TEE, 1/4 tube O.D. with swivel nut on one end	1

Note: Use this parts list for engines with the exhaust by-pass valve installed as shown in Figure 12, Installation B.

- | | |
|--------------------------------------|---|
| * Uses a P/N MS29512-02 O-ring. | ● Drain fitting installed in the accy. housing to clock the fitting to the 7 O'clock position |
| ** Uses a P/N MS29512-04 O-ring. | ■ Install straight end of the hose to the accy. housing |
| *** Uses a P/N MS29512-06 O-ring. | ◆ Install the 90° end to the fuel pump vent fitting |
| + Ship loose (Cessna oil separator). | |




Figure 15
Intake Pipes, Air Inlet Housing, and Attaching Parts

Figure 15 – Intake Pipes, Air Inlet Housing, and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		70485	PIPE, Intake	6
2		69603	HOSE, 1-3/4 I.D. x 2-3/16 O.D. x 1-3/4 long	6
3		LW-15592-8-28	CLAMP, Hose	12
4		71973	GASKET, 2 bolt flange, 1-3/4 I.D.	6
5		73346	FLANGE, Intake pipe, upper	6
6		STD-8	WASHER, 1/4 plain	12
7		STD-160	WASHER, 1/4 lock, internal teeth	12
8		LW-25-1.25	BOLT, 1/4-20 x 1-1/4 long, hex. head	12
9		78366	HEAT SHIELD, (1, 2, 4, & 6 intake pipes)	4
10		LW-15592-8-24	CLAMP, Hose, 1-13/16 dia. x 9/16 wide	8
11		02M22920	HOSE, 2.00 to 2-1/2 I.D. x 2-7/8 long	1
12		LW-15858-62-294	CLAMP, T-bolt	1
13		LW-15858-62-244	CLAMP, T-bolt	1
14		77504	GASKET, Fuel Injector	1
15		41A22811	HOUSING, Air inlet	1
16		02A22460	ELBOW, Street, 1/8-27 NPT, 45°	1
17		LW-13807	ADAPTER ASSEMBLY, Fuel drain valve	1
18		LW-14445-10	VALVE ASSEMBLY, Absolute pressure relief	1
19		MS29513-138	O-RING	1
20		STD-28	WASHER, No. 10 plain	4
21		STD-251	WASHER, No. 10, internal lock	4
22		STD-2248	SCREW, No. 10-24 x 5/8 long	4
23		STD-8	WASHER, 1/4 plain	4
24		STD-160	WASHER, 1/4 long, internal teeth	4
25		LW-25-0.94	BOLT, 1/4-20 x 15/16 long, hex. head	3
26		LW-25-0.81	BOLT, 1/4-20 x 13/16 long, hex. head	1
27		MS29512-04	O-RING, 11/32 I.D. x 1/16 section	1
28		AN814-4L	PLUG & BLEEDER, 7/16-20 UNF, drilled	1




Figure 16
Oil Level Gage Assembly and Engine Mounting Brackets

Figure 16 - Oil Level Gage Assembly and Engine Mounting Brackets

Figure Item	Code	Part Number	Description	Units per Assembly
1		70457	GASKET, Oil filler extension	1
2		75675	EXTENSION, Oil filler, 2-3/16 long	1
3		74065	RING, Oil level gage seal	1
4		LW-16783-24	GAGE ASSEMBLY, Oil level	1
5		12A19770	BRACKET, Engine mounting, dynafocal	4
6		STD-33	WASHER, 3/8 plain	16
7		STD-678	WASHER, 3/8 lock, internal teeth	16
8		STD-596	NUT, 3/8-24 plain	16




Figure 17
Oil Sump Assembly, Induction Housing, and Oil Suction Screen

Figure 17 – Oil Sump Assembly, Induction Housing, and Oil Suction Screen

Figure Item	Code	Part Number	Description	Units per Assembly
1		06B21326	GASKET, Oil sump	1
2		LW-19168	SUMP ASSEMBLY, Oil	1
3		71699	CONNECTION, Intake pipe	6
4		25C-11	STUD, 1/4-20 x 1-3/8 long	13
5		25C-14	STUD, 1/4-20 x 1-3/4 long	1
6		STD-1164	INSERT, 5/16-18 x 5/8 long, helicoil	4
7		38-15	STUD, 3/8-16 x 1-7/8 long	8
8		STD-1173	INSERT, 1/4-20 x 0.500 long	4
9		STD-1171	INSERT, 3/8-16 x 3/4 helicoil	3
10		1102	PLUG, 1/8-27 NPT, Allen head	1
11		STD-8	WASHER, 1/4 plain	34
12		STD-160	WASHER, 1/4 lock, internal teeth	27
13		LW-25-1.13	BOLT, 1/4-20 x 1-1/8 long, hex. head	5
14		LW-25-1.00	BOLT, 1/4-20 x 1.00 long, hex. head	6
15		LW-25-1.25	BOLT, 1/4-20 x 1-1/4 long, hex. head	2
16		STD-1411	NUT, 1/4-20 plain	21
17		STD-551	PLUG, 1/2-14 NPT, square head	2
18		74655	SPACER, Exhaust manifold bracket	1
19		07H21150	BRACKET, Exhaust manifold cable retainer	1
20		73152	BRACKET, Support	4
21		70484	SCREEN, Oil suction	1
22		06E19769-1.00	GASKET, 1.00 I.D. x 1-1/4 O.D. x 3/32 annular	1
23		LW-12545	PLUG, 5/8 hex. head x 1.00-20 thread	1




Figure 18
Accessory Housing Assembly

Figure 18 – Accessory Housing Assembly

Figure Item	Code	Part Number	Description	Units per Assembly
1		73818	GASKET, Accessory housing	1
2		21C21542-06	HOUSING ASSEMBLY, Accessory	1
3		31C-19	STUD, 5/16-18 x 2-3/8 long	4
4		31C-12	STUD, 5/16-18 x 1-1/2 long	4
5		31C-21	STUD, 5/16-18 x 2-5/8 long	4
6		25C-14	STUD, 1/4-20 x 2-3/8 long, drilled	3
7		25C-31	STUD, 1/4-20 x 2-5/8 long	1
8		MS-20822-4	ELBOW, 1/8 NPT to 1/4 tube, 90°	1
9		1102	PLUG, 1/8-27 NPT, Allen head	3
10		31CD-20	STUD, 5/16-18 x 2-1/2 long, drilled	3
11		76156	SHIELD, Oil Accessory Breather	1




Figure 19
Oil Pump Assembly and Accessory Housing Attaching Parts

Figure 19 – Oil Pump Assembly and Accessory Housing Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		51A22618	BODY ASSEMBLY, Oil pump	1
2		51D22617	SHAFT, Oil pump drive	1
3		STD-714	COTTER PIN, 1/8 diameter x 1.00 long	1
4		STD-1339	PLUG, 1/16-27 NPT, Allen head	1
5		76784	SHAFT, Oil pump drive	1
6		05K23463	KIT, Oil pump impellers	1
	P	51B23274	IMPELLER, Oil pump, driving	1
	P	51C23290	IMPELLER ASSEMBLY, Oil pump, driven	1
7		STD-35	WASHER, 5/16 plain	3
8		STD-1420	NUT, 5/16-18 slotted	3
9		LW-14260	SEAL, Tachometer drive, oil	1
10		STD-8	WASHER, 1/4 plain	12
11		STD-160	WASHER, 1/4 lock, internal teeth	12
12		LW-25-0.94	BOLT, 1/4-20 x 15/16 long, hex. head	9
13		LW-25-1.13	BOLT, 1/4-20 x 1-1/8 long, hex. head	1
14		LW-25-1.44	BOLT, 1/4-20 x 1-7/16 long, hex. head	2
P Sold in complete sets only (Kit P/N 05K23463).				




Figure 20
Fuel Pump Assembly and Attaching Parts

Figure 20 - Fuel Pump Assembly and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-10799	SPACER, Fuel pump insulating	1
2		62D26037	FUEL PUMP, HET 201F-5008	1
3		STD-35	WASHER, 5/16 plain	4
4		STD-475	WASHER, 5/16 lock, internal teeth	4
5		STD-1410	NUT, 5/16-18 plain	4
6		02G21379	NIPPLE, 1/8 NPT to 1/4 tube (Fuel pump vent)	1
7		MS20822-6	ELBOW, 1/4 NPT to 3/8 flared tube (inlet and outlet)	2




Figure 21
Hydraulic Pump Drive and Cover

Figure 21 – Hydraulic Pump Drive and Cover

Figure Item	Code	Part Number	Description	Units per Assembly
1		72964	GEAR ASSEMBLY, Hydraulic pump driven	1
2		72962	THRUST BUTTON, Vacuum pump gear	1
3		71596	WASHER, Accessory drive gear	1
4		68315	GASKET, Accessory drive adapter	1
5	*	27D21250	ADAPTER ASSEMBLY, Hydraulic pump	1
6		27D21249	ADAPTER, Hydraulic pump	1
7		06A19956	OIL SEAL, 7/8 I.D. x 1-1/2 O.D. x 5/16 wide	1
8		25C-12	STUD, 1/4-20 x 1-1/2 long	4
9		STD-1774	PIN, 1/8 diameter x 1/4 long	1
10		01N19833-187	PLUG, Pin	1
11		STD-35	WASHER, 5/16 plain	4
12		STD-475	WASHER, 5/16 lock, internal teeth	4
13		STD-1410	NUT, 5/16-18 plain	4
14		8313	GASKET, Vacuum pump	1
15		60430	COVER, Vacuum pump	1
16		STD-8	WASHER, 1/4 plain	4
17		STD-160	WASHER, 1/4 lock, internal teeth	4
18		STD-1411	NUT, 1/4-20 plain	4
19		69551	GASKET, Accessory drive adapter (flat tappet)	1
20		69106	COVER, Governor drive adapter pad (flat tappet)	1
* No provision for oil supply				




Figure 22
Turbo Scavenge Pump and Vacuum Pump Drive and Cover

Figure 22 – Turbo Scavenge Pump and Vacuum Pump Drive and Cover

Figure Item	Code	Part Number	Description	Units per Assembly
1		61183	GASKET, Accessory adapter	1
2		29A22457	DRIVE ASSEMBLY, Turbo scavenge & hydraulic pump	1
3		29A22456	ADAPTER ASSEMBLY, Turbo scavenge pump	1
4		25C-11	STUD, 1/4-20 x 1-38 long	3
5		STD-1774	PIN, 1/8 diameter x 1/4 long	2
6		29D22366	ADAPTER, Vacuum pump	1
7		MS28775-137	O-RING	1
8		29E22367	SHAFT, Vacuum pump drive	1
9		STD-95	KEY, 1/8 x 1/2 woodruff	1
10		LW-15550	GEROTOR PUMP	1
11		06A19956	OIL SEAL, 7/8 I.D. x 1-1/2 O.D. x 5/16 wide	1
12		29H22368	SHAFTGEAR, Vacuum pump drive	1
13		77708	WASHER, Retaining propeller governor drive	1
14		MS16562-28	PIN, 3/32 diameter x 3/4 long, slotted	1
15		25C--10	STUD, 1/4-20 x 1-1/2 long	4
16		STD-8	WASHER, 1/4 plain	3
17		STD-160	WASHER, 1/4 lock, internal teeth	3
18		STD-1411	NUT, 1/4-20 plain	3
19		STD-8	WASHER, 1/4 plain	4
20		STD-160	WASHER, 1/4 lock, internal teeth	4
21		STD-1411	NUT, 1/4-20 plain	4
22		8313	GASKET, Pump	1
23		60430	COVER, Pump	1
24		STD-8	WASHER, 1/4 plain	4
25		STD-160	WASHER, 1/4 lock, internal teeth	4
26		STD-1411	NUT, 1/4-20 plain	4




Figure 23
Oil Filter Assembly, Oil Cooler Bypass Valve, and Breather Fitting

Figure 23 – Oil Filter Assembly, Oil Cooler Bypass Valve, and Breather Fitting

Figure Item	Code	Part Number	Description	Units per Assembly
1	*	06B23862	GASKET, Oil filter adapter	2
2		77852	OIL FILTER BASE ASSEMBLY	1
3	**	LW-13215	OIL FILTER, Short, CH48110-1	1
4		STD-8	WASHER, 1/4 plain	4
5		STD-160	WASHER, 1/4 lock, internal teeth	1
6		STD-1411	NUT, 1/4-20 plain	1
7		LW-25-1.00	BOLT, 1/4-20 x 1.00 long hex	3
8		STD-160	WASHER, 1/40 lock, internal teeth	3
9		53E22144	VALVE ASSEMBLY, Temperature control, oil cooler by-pass	1
10		25C-10	STUD, 1/4-20 x 1-1/4 long	1
11		AN840-12D	FITTING, Breather	1
12	+	STD-2238	NIPPLE, -10 to -6 special	2
13		06E19769-0.63	GASKET, Annular, 5/8 I.D.	1
14		62417	PLUG, Oil cooler bypass	1
15		02A23027	ELBOW, 45°, 3/8 NPT to 5/8 flared tube	1
* Extra gasket shipped as loose part with engine. ** Refer to latest edition of Textron Lycoming SSP-885 for oil filter kits and replacement filters. + Extra nipple shipped as loose part with engine.				




Figure 24
Fuel Injector, Fuel Manifold, and Injection Nozzles

Figure 24 – Fuel Injector, Fuel Manifold, and Injection Nozzles

Figure Item	Code	Part Number	Description	Units per Assembly
1		66224	GASKET, Carburetor	1
2		61J23431	FUEL INJECTOR , 2576592-2	1
3		STD-35	WASHER, 5/16 plain	4
4		STD-475	WASHER, 5/16 lock, internal teeth	4
5		LW-31-1.31	BOLT, 5/16-18 x 1-5/16 long hex	4
6		63B31561	MANIFOLD ASSEMBLY, Fuel	1
7		AN816-4	NIPPLE, 1/8 NPT to 1/4 tube	1
8		STD-148	NIPPLE, Union, 1/8 NPT	5
9		1102	PLUG, 1/8-27 NPT, Allen head	1
10		63C26453	NOZZLE ASSEMBLY, Manifold air bleed	6
11		73966	SPACER, Fuel manifold bracket	2
12		07A22995	BRACKET, Fuel manifold	2
13		STD-251	WASHER, No. 10 internal teeth	4
14		STD-82	SCREW, No. 10-24 x 1/2 long, fill. head	4





Figure 25
Fuel Lines and Attaching Parts

Figure 25 – Fuel Lines and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1		LW-12098-0-210	TUBE ASSEMBLY, Fuel injector line	4
2		LW-12098-0-170	TUBE ASSEMBLY, Fuel	2
3		LW-16266-10-75	CLAMP	12
4		LW-16266-10-13	CLAMP, 1/8 diameter for No. 10 screw	12
5		STD-860	SCREW, No. 10-32 x 5/8 long, fill. head	12
6		STD-425	WASHER, No.10 plain	2
7		STD-670	LOCK NUT, No. 10-32 self-locking	12
8		LW-12798-4S303	HOSE ASSEMBLY, 1/4 hose, straight	1
9		LW-16266-25-63	CLAMP, 5/8 I.D. x 1/4 diameter screw	1
10		LW-12798-4S150	HOSE ASSEMBLY, 3/8 hose, 45° elbow	1
11		AN815-4	UNION, 1/4 flared tube	1
12		LW-16266-10-63	CLAMP, 5/8 I.D. x No. 10 screw	1
13		73136	BRACKET, Extension	2
14		74655	SPACER, Exhaust manifold	1
15		STD-8	WASHER, 1/4 plain	1
16		STD-160	WASHER, 1/4 lock, internal teeth	1
17		LW-25-0.94	BOLT, 1/4-20 x 15/16 long hex.	1
18		07A28507	BRACKET ASSEMBLY, Fuel line support	2
19		STD-860	SCREW, No.10-32 x 5/8 long fill. head	1
20		STD-692	SCREW, No.10-32 x 1/2 long, round head	2
21		STD-425	WASHER, No.10 Plain	2
22		STD-670	LOCK NUT, No.10-32	1
23		LW-12879-6S262	HOSE ASSEMBLY, 3/8 hose, 45° elbow	1
24		02G21379	NIPPLE, 1/8 NPT to 1/4 tube	1
25		MS20822-6	ELBOW, 1/4 NPT to 3/8 flared tube	2



050AD

Figure 26
Injector Nozzle Vent Manifolds, Hoses and Attachments

FIGURE 26 – INJECTOR NOZZLE VENT MANIFOLDS, HOSES AND ATTACHMENTS

Figure Item	Code	Part Number	Description	Units per Assembly
1		63E21054	MANIFOLD, Injector nozzle vent, right	1
2		78109	MANIFOLD, Injector nozzle vent, left	1
3		LW-18737	HOSE, 3/16 I.D. x 7/16 O.D. x 2.00 long	6
4		LW-15592-5-03	CLAMP, 0.438 O.D. hose	12
5		LW-16266-10-25	CLAMP, 1/4 I.D. for #10 screw	4
6		73152	BRACKET, Support clamp	4
7		STD-1856	SCREW, 1/4-20 x 1.00 long, hex. head	4
8		STD-2079	NUT, 1/4-20 UNC	4
		01B31661-251	LOCKNUT-Prevailing torque, 1/4-20 UNC-2B, Thin	4
9		STD-692	SCREW, #10-32 x 1/2 long, round head	4
10		STD-670	LOCKNUT, 10-32 self-locking	4
11		STD-1339	PLUG, 1/16-27 NPT	4
12		63A22481	TUBE, Crossover, nozzle vent, man.	1
13		63A22482	TUBE, Crossover, nozzle vent, man.	1
14		AN824-4	TEE, 1/4 flared tube	1
15		STD-2048	HOSE, 1/4 I.D. x 0.59 O.D. x 2.44 long	2
16		LW-15592-5-03	CLAMP, 0.438 O.D. hose	4
17		78753	BRACKET, Injector nozzle vent crossover	1
18		LW-16266-10-25	CLAMP, 1/4 I.D. for #10 screw	1
19		STD-692	SCREW, #10-32 x 1/2 long, round head	1
20		STD-670	LOCKNUT, 10-32 self-locking	1
21		LW-12798-4S340	HOSE ASSY, 1/4 hose, straight	1
22		73944	1/4 tube, AFJ, 45 bypass valve	1
23		07A28507	BRACKET ASSY, Fuel line support	1
24		LW-16266-10-63	CLAMP, 5/8 I.D. for #10 screw	1
25		STD-860	SCREW, #10-32 x 5/8 long, fill. head	1
26		STD-692	SCREW, #10-32 x 1/2 long, round head	2
27		STD-425	WASHER, #10 plain	2
28		STD-670	LOCKNUT, 10-32 self-locking	1




Figure 27
Magnetos, Magneto Drives, Harnesses, and Spark Plugs

Figure 27 – Magnetos, Magneto Drives, Harnesses, and Spark Plugs

Figure Item	Code	Part Number	Description	Units per Assembly
1		68H22624	CUSHION, Magneto drive	4
2		MS9245-44	COTTER PIN, 3/32 diameter x 5/8 long	2
3		LW-19096	GEAR RETAINER ASSEMBLY	1
4		67542	BALL BEARING	1
5		62224	GASKET, Magneto adapter	2
6		LW-12707	ADAPTER, Magneto, left, impulse coupling	1
7		LW-13926	ADAPTER, Magneto	1
8		LW-12681	GASKET, Magneto, right	2
9		66LC35SDNP	MAGNETO, Impulse 6361	2
10		67J20608-P	HARNESS, Right, Slick P/N M-2966	1
11		67J20609-P	HARNESS, Left, Slick P/N M-2965	1
12		76734	ZIP STRAP	4
13		66M21195	CLAMP, Magneto	4
14		STD-475	WASHER, 5/16 lock, internal teeth	4
15		STD-1410	NUT, 5/16-18 plain	4
16		STD-2007	WASHER, 3/8 diameter seal	1
17		STD-33	WASHER, 3/8 plain	7
18		LW-13227	ADAPTER, Magneto pressurization	1
19		LW-13226	NUT, 3/8-16 plain	1
20		66N21020	VALVE ASSEMBLY, Relief	1
21		MS29512-04	O-RING, 11/32 I.D. x 1/16 section	1
22		AN825-4	TEE, 1/4 flared tube x 1/8 NPT	1
23		LW-12798-4S204	HOSE ASSEMBLY, 1/4 hose, straight	1
24		LW-12798-4S303	HOSE ASSEMBLY, 1/4 hose, straight	1
25		MS20822-4	ELBOW, 1/8 NPT to 1/4 tube, 90°	2
26		LW-16266-25-25	CLAMP, One wire	2
27		71824	CLAMP, Rubber dip, two wire	2

(continued on next page)

Figure 27 – Magnetos, Magneto Drives, Harnesses, and Spark Plugs (Cont.)

Figure Item	Code	Part Number	Description	Units per Assembly
28		LW-16266-25-56	CLAMP, 7/16 I.D. x 1/4 diameter screw	3
29		STD-1925	SCREW, 1/4-20 x 5/8 long, pan head, self-locking	2
30		73136	BRACKET, Extension, fuel injector line	1
31	*	1182-H7	SPARK PLUG, Champion P/N RHB37E	12
* Refer to the latest revision of Lycoming Service Instruction No. 1042 for complete listing of all approved spark plugs.				

This page intentionally left blank




Figure 28
Exhaust Pipes and Transition Assembly

Figure 28 - Exhaust Pipes and Transition Assembly

Figure Item	Code	Part Number	Description	Units per Assembly
1		77611	GASKET, Exhaust flange	6
2		40G22959	PIPE, Exhaust adapter cyl. No. 2 & No. 3	2
		40G23394	PIPE, Exhaust adapter cyl. No. 2 & No. 3 (with EGT probe holes)	2
3		40B22962	PIPE, Exhaust, cyl. No. 2	1
4		40B22964	PIPE, Exhaust cyl. No. 4	1
		40B23391	PIPE, Exhaust cyl. No. 4 (with EGT probe holes)	1
5		40B22966	PIPE, Exhaust cyl. No. 6	1
		40B23390	PIPE, Exhaust cyl. No. 6 (with EGT probe holes)	1
6		40B22961	PIPE, Exhaust cyl. No.1 & 3	1
		40B23392	PIPE, Exhaust cyl. No.1 & 3 (with EGT probe holes)	1
7		40B22965	PIPE, Exhaust cyl. No. 5	1
		40B23393	PIPE, Exhaust cyl. No. 5 (with EGT probe holes)	1
8		40C22960	FLANGE, Exhaust transition	1
9		40D23026	COUPLING, V-band	1
10		78084	GASKET, V-band coupling 2.00 tube	1
11		STD-2233	NUT, 5/16-18 self-locking	12
12		AN960C516	WASHER, 5/16 plain	12
13		47C22923	TRANSITION, Exhaust	1
14		LW-19189	CABLE, Exhaust manifold retainer	1
15		STD-1411	NUT, 1/4-20 plain	2
16		LW-25SS-0.75	BOLT, 1/4-20 x 3/4 long, hex. head	1
17		STD-2044	NUT, 1/4-20 self-locking	1
18		07C23103	CLAMP, Exhaust pipe	1




Figure 29
Starter Assembly and Attaching Parts

Figure 29 - Starter Assembly and Attaching Parts

Figure Item	Code	Part Number	Description	Units per Assembly
1	*	31B26040	STARTER ASSEMBLY, Kelly ERB-8011 - 24 VOLT, 12/14 pitch (roller tappet)	1
1		31B26554	STARTER, Sky Tec, 12/14 pitch, 24V, 149NL/EC (flat tappet)	1
2		STD-475	WASHER, 5/16 lock, internal teeth	4
3		LW-31-1.16	BOLT, 0.3125-18 x 1.16 long, hex head (roller tappet)	1
3		LW-31-0.94	BOLT, 0.3125-18 x .94 long, hex head (flat tappet)	1
4		STD-1410	NUT, 5/16-18 plain	3
5		STD-35	WASHER, 5/16 plain	4
* Refer to the latest revision of Service Instruction No. 1154 for a complete list of FAA-approved starters and alternators.				

This page intentionally left blank

Service Kit Section**Seal and Gasket Set**

PART NO.	PART NAME	Qty.
05K23204	KIT - SEAL AND GASKET SET	1
68H22624	CUSHION- Magneto Drive	4
06B23862	GASKET - Oil Filter Adapter	1
06B26669	GASKET - Rocker Box Cover (Silicone)	6
70455	GASKET-.78 ID X 1.13 OD X .060	1
71973	GASKET-2 Bolt Flange-1.81 ID	6
61183	GASKET-Accessory Adapter	1
68315	GASKET-Accessory Drive Adapter	1
73818	GASKET-Accessory Housing	1
06E19769-0.63	GASKET-ANNULAR-.625 ID	1
06E19769-1.00	GASKET-ANNULAR-1.000 ID	1
06E19769-1.25	GASKET-ANNULAR-1.250 ID	1
66224	GASKET-Carburetor	1
77611	GASKET-Exhaust Flange	6
77504	GASKET-Fuel Injector	1
69164	GASKET-Fuel Pump Adapter	1
72053	GASKET-Governor	1
62224	GASKET-Mag Adapter	2
LW-12681	GASKET-Magneto	2
70457	GASKET-Oil Filler Extension	1
06B21326	GASKET-Oil Sump	1
LW-18038	GASKET-Turbo Oil Drain Adapter	1
77813	GASKET-Turbo Oil Inlet	1
75845	GASKET-V Band Coupling-2.25	1
78084	GASKET-V Coupling 2.00 Tube (17189-200n)	1
8313	GASKET-Vacuum Pump	2
STD-1821	HOSE-.38 X 2.50 LONG	6
69603	HOSE-1.75 ID X 2.188 OD X 1.75	6
02M22920	HOSE-2.000 TO 2.50 I.D. X 2.880 LONG	1
71667	LOCKPLATE-.250 BOLT X 1.75	1
73383	LOCKPLATE-.3125 BOLT X 1.00	1
LW-18638	LOCKPLATE-Crankshaft Gear	1
LW-12272	LOCKPLATE-Shroud Tube	6
MS29512-02	O RING-.239 ID X .064 SECT.	1
MS29512-04	O RING-.351 ID X .072 SECT.	4
MS29512-06	O RING-.468 ID X .078 SECT.	7
MS29512-08	O RING-.644 ID X .087 SECT.	2

Seal and Gasket Set (Cont.)

PART NO.	PART NAME	Qty.
MS29513-138	O RING-2.112 ID X .103 SECT	1
STD-213	OIL SEAL.75 ID X 1.375 OD	1
06A19956	OIL SEAL-.875ID X 1.50 OD X.31	2
STD-1737	RING-External Retaining-.56 DIA	1
LW-14820	RING-Internal Retaining	8
74065	RING-Oil Level Gage Seal	1
71481	RING-Oil Seal-.09 DIA X 4.84 ID	6
72091	RING-OIL SEAL-.36ID X.10 DIA	2
LW-13792	SEAL-Crankshaft-Oil	1
LW-18661	SEAL-Shroud Tube	12
70310	SEAL-Shroud Tube	12
LW-14260	SEAL-Tachometer Drive-Oil	1
LW-14995	SPRING-Shroud Tube	6

Cylinder, Piston and Ring Assembly

PART NO.	PART NAME	Qty.
05K22680	KIT - CYLINDER, PISTON AND RING ASSEMBLY	1
16G23273-02	CYLINDER HEAD & VALVE ASSEMBLY	1
14D23907	PISTON, Compression ratio 7.30:1	1
74241	RING, Piston, compression, 5-1/8 bore	2
14H29884	RING, Piston, oil, 5-1/8 bore	1
LW-14078	PIN, Piston	1
72198	PLUG, Piston pin	2
66732	GASKET, Valve rocker shaft cover	2
06B28890	GASKET, Rocker box cover (silicone)	1
LW-18661	SEAL, Shroud tube	4
70310	SEAL, Shroud tube	2
LW-12272	LOCKPLATE, Shroud tube	1
71481	RING, Oil seal, 9/100 diameter x 4-27/32 I.D.	1
SSP-299	TAG	1
71195	CONTAINER	1
71973	GASKET, 2 bolt flange, 1-13/16 I.D.	1
LW-18234	GASKET, Exhaust flange	2
AV951391	PACKING, Pre-formed	2
06A23493	SEAL, Shroud tube	2
STD-148	NIPPLE, Union, 1/8 NPT	1
SSP-115	STICKER	
1102	PLUG, 1/8 pipe	1

Crankshaft and Counterweight Assembly Kit

PART NO.	PART NAME	Qty.
05K47677	KIT - CRANKSHAFT AND COUNTERWEIGHT ASSEMBLY	1
13E47622	CRANKSHAFT ASSEMBLY	1
LW-19210	COUNTERWEIGHT ASSEMBLY	2
LW-15558	ROLLER, Dynamic counterweight	2
76788	ROLLER, Dynamic counterweight, 6.3 order	2
71907	WASHER, Counterweight	8
LW-14820	RING, Internal retaining	8

NUMERICAL INDEX

PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
01B31661-251	LOCKNUT	55	1182-H7	SPARK PLUG	56
01L21418	WASHER	3	11E24005-S	C'CASE ASSY	5
01L23459	WASHER	19	11E24005-S1	C'CASE ASSY	5
01N19833-187	PLUG	43	11E24105-S1	C'CASE ASSY	5
02A22460	ELBOW	31	12A19770	BRACKET	33
02A22992	TEE	29	13E47622	C'SHAFT ASSY	9
02A23027	ELBOW	47	13S19648	GEAR	9
02G21379	NIPPLE	41	14D23913	PISTON	15
02G21379	NIPPLE	51	14H29889	RING	15
02G22466	NIPPLE	29	14S23890	BOLT	15
02G22988	NIPPLE	29	15B21319	SOCKET	19
02M22920	HOSE	31	15B26066	PLUNGER ASSY	19
05K23463	KIT	39	15B26588	BODY	7
06A19956	OIL SEAL	43	15F28835-28	ROD ASSEMBLY	19
06A19956	OIL SEAL	45	15F28835-29	ROD ASSEMBLY	19
06A23493	SEAL	19	15F28835-30	ROD ASSEMBLY	19
06B21326	GASKET	35	15F28835-31	ROD ASSEMBLY	19
06B23862	GASKET	47	15F28835-32	ROD ASSEMBLY	19
06B26669	GASKET	23	15F28835-33	ROD ASSEMBLY	19
06E19769-0.63	GASKET	47	15F28835-34	ROD ASSEMBLY	19
06E19769-1.00	GASKET	35	15F28835-35	ROD ASSEMBLY	19
06E19769-1.25	GASKET	7	15F28835-36	ROD ASSEMBLY	19
07A21443	BRACKET	1	15F28835-37	ROD ASSEMBLY	19
07A22810	BRACKET	25	15G23461	SHROUD TUBE	19
07A22955	BRACKET	27	15N23373	CAMSHAFT	9
07A22995	BRACKET	49	15N23374	CAMSHAFT ASSY	9
07A28507	BRACKET ASSY	51	16A30100-01	CYL & HEAD ASSY	17
07A28507	BRACKET ASSY	53	16A30100-01	CYL & HEAD ASSY	19
07C23103	CLAMP	59	16R22126	GUIDE	17
07H21150	BRACKET	35	17A23938	VALVE	19
1028-B	BALL	7	17B23936	VALVE	19
1102	PLUG	5	17C19386	CAP	19
1102	PLUG	17	17C21191	KEY	19
1102	PLUG	20	17D29055	SPRING	19
1102	PLUG	35	17D29060	SPRING	19
1102	PLUG	37	17F19357	ROCKER ASSY	20
1102	PLUG	49	18A26093	BEARING	7



PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
18D26098	BEARING	7	40B23393	PIPE	59
18M26105	BEARING	15	40C22960	FLANGE	59
21C21542-06	HOUSING ASSY	37	40D22383	COUPLING	25
25C-10	STUD	47	40D23026	COUPLING	59
25C-10	STUD	45	40G22959	PIPE	59
25C-11	STUD	35	40G23394	PIPE	59
25C-11	STUD	45	41A22811	HOUSING	31
25C-12	STUD	43	46C22924	TURBOCHARGER	25
25C-14	STUD	35	47C22923	TRANSITION	59
25C-14	STUD	37	48B22970	CONTROLLER	29
25C-31	STUD	37	51A22618	BODY ASSEMBLY	39
25C-8	STUD	17	51B23274	IMPELLER	39
27D21249	ADAPTER	43	51C23290	IMPELLER ASSY	39
27D21250	ADAPTER ASSY	43	51D22617	SHAFT	39
29A22456	ADAPTER ASSY	45	53E22144	VALVE ASSEMBLY	47
29A22457	DRIVE ASSEMBLY	45	58B22954	TANK	27
29D22366	ADAPTER	45	60009	KEY	19
29E22367	SHAFT	45	60430	COVER	43
29H22368	SHAFTGEAR	45	60430	COVER	45
31B26040	STARTER ASSY	61	60463	TUBE	9
31B26554	STARTER	61	60803	STRAP	13
31C-12	STUD	17	61084	SPRING	7
31C-12	STUD	37	61183	GASKET	45
31C-17	STUD	5	61247	COVER	23
31C-19	STUD	37	61J23431	FUEL INJECTOR	49
31C-21	STUD	37	62224	GASKET	55
31CD-20	STUD	37	62417	PLUG	47
31M22993	SUPPORT ASSY	9	62D26037	FUEL PUMP	41
38-15	STUD	35	63A22481	TUBE	53
383-B	NUT	23	63A22482	TUBE.	53
40B22961	PIPE	59	63B31561	MANIFOLD ASSY	49
40B22962	PIPE	59	63C26453	NOZZLE ASSY	49
40B22964	PIPE	59	63E21054	MANIFOLD	53
40B22965	PIPE	59	65441	SEAT	19
40B22966	PIPE	59	66224	GASKET	49
40B23390	PIPE	59	66610	BUSHING	17
40B23391	PIPE	59	66LC35SDNP	MAGNETO	55
40B23392	PIPE	59	66M21195	CLAMP	55

PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
66N21020	VALVE ASSEMBLY	55	72053	GASKET	3
67530	BUSHING	11	72057	SEAT	17
67542	BALL BEARING	55	72058	SEAT	17
67J20608-P	HARNESS	55	72091	RING	7
67J20609-P	HARNESS	55	72155-S	BUSHING	9
68315	GASKET	43	72198	PLUG	15
68484	TUBE	9	72246	SHAFT	11
68668	SPRING	7	72376-CT	ELBOW	29
68759	TUBE ASSEMBLY	23	72376-CT	ELBOW	31
68761	TUBE ASSEMBLY	23	72377	ELBOW	29
68H22624	CUSHION	55	72378	COVER	3
69106	COVER	43	72566	GEAR	9
69159	ADAPTER ASSY	11	72962	THRUST BUTTON	11
69164	GASKET	11	72962	THRUST BUTTON	43
69260	INSERT	17	72964	GEAR ASSEMBLY	43
69551	GASKET	43	72972	SHAFTGEAR	11
69603	HOSE	31	73136	BRACKET	51
70310	SEAL	19	73136	BRACKET	56
70455	GASKET	3	73152	BRACKET	29
70457	GASKET	33	73152	BRACKET	35
70474	WASHER	11	73152	BRACKET	53
70484	SCREEN	35	73249	WASHER	3
70485	PIPE	31	73250	WASHER	3
71481	RING	17	73251	WASHER	3
71481	RING	23	73252	WASHER	3
71596	WASHER	43	73346	FLANGE	31
71610	HOOK	23	73383	LOCKPLATE	1
71611	RETAINER	23	73772	NOZZLE ASSY	5
71640	PLUG	9	73818	GASKET	37
71664	GEAR ASSEMBLY	11	73944	TUBE	53
71667	LOCKPLATE	11	73966	SPACER	13
71668	GEAR ASSEMBLY	11	73966	SPACER	49
71699	CONNECTION	35	74065	RING	33
71737	TUBE ASSEMBLY	23	74070	ELBOW	29
71824	CLAMP	55	74241	RING	15
71903-A	BUSHING	9	74494	PLATE	23
71907	WASHER	9	74637	BUSHING	20
71973	GASKET	31	74655	SPACER	35

PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
74655	SPACER	51	78366	HEAT SHIELD	31
74887	SPACER	23	78753	BRACKET	53
75656-S	BUSHING	9	8313	GASKET	43
75657-S	BUSHING	9	8313	GASKET	45
75675	EXTENSION	33	AN310-6	NUT	7
75739-CT	NIPPLE	5	AN565B1032H5	SET SCREW	3
75739-CT	NIPPLE	29	AN6-34A	BOLT	13
75845	GASKET	25	AN6C12A	BOLT	25
75906	GASKET	23	AN814-4L	PLUG & BLEEDER	29
76118	SPACER	9	AN814-6L	PLUG	5
76154	SHAFT	9	AN815-4	UNION	51
76155	SHAFT ASSY	9	AN816-4	NIPPLE	49
76156	SHIELD	37	AN824-4	TEE	53
76159	PLUG	7	AN825-4	TEE	55
76161	CAP	7	AN840-12D	FITTING	47
76162	INSERT	7	AN912-9	BUSHING	29
76220	STUD	13	AN960C516	WASHER	25
76734	ZIP STRAP	27	AN960C516	WASHER	27
76734	ZIP STRAP	55	AN960C516	WASHER	59
76784	SHAFT	39	AN960C616	WASHER	25
76788	ROLLER	9	LRT23381	BODY	7
76908	STRUT	1	LW-10077	SEAT	19
76943	GUIDE	17	LW-10442	GEAR	3
77309	BUSHING	11	LW-10541	GEAR ASSEMBLY	3
77467	SPRING	7	LW-10799	SPACER	41
77504	GASKET	31	LW-11485	SHROUD TUBE	19
77611	GASKET	59	LW-11713	SPRING	7
77708	WASHER	45	LW-11750	CONN ROD	15
77807	SCREW	7	LW-11750-S	CONN ROD ASSY	15
77808	VALVE ASSY	7	LW-11795	SPRING	19
77813	GASKET	27	LW-11800	SPRING	19
77852	OIL FILTER BASE	47	LW-12098-0-170	TUBE ASSEMBLY	51
77872	BUSHING	3	LW-12098-0-210	TUBE ASSEMBLY	51
77906	SPACER	23	LW-12186	NUT	15
78084	GASKET	59	LW-12272	LOCKPLATE	19
78109	MANIFOLD	53	LW-12287	ADAPTER	27
78212	VALVE ASSEMBLY	27	LW-12545	PLUG	35
78303	TEE	29	LW-12681	GASKET	55

PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
LW-12707	ADAPTER	55	LW-15592-5-03	CLAMP	53
LW-12798-4S111	HOSE ASSEMBLY	29	LW-15592-5-04	CLAMP	23
LW-12798-4S130	HOSE ASSEMBLY	29	LW-15592-8-24	CLAMP	31
LW-12798-4S150	HOSE ASSEMBLY	51	LW-15592-8-28	CLAMP	31
LW-12798-4S204	HOSE ASSEMBLY	55	LW-15858-62-244	CLAMP	31
LW-12798-4S274	HOSE ASSEMBLY	29	LW-15858-62-294	CLAMP	31
LW-12798-4S303	HOSE ASSEMBLY	29	LW-16266-10-13	CLAMP	51
LW-12798-4S303	HOSE ASSEMBLY	51	LW-16266-10-25	CLAMP	53
LW-12798-4S303	HOSE ASSEMBLY	55	LW-16266-10-63	CLAMP	29
LW-12798-4S340	HOSE ASSY	53	LW-16266-10-63	CLAMP	51
LW-12799-6S180	HOSE ASSEMBLY	29	LW-16266-10-63	CLAMP	53
LW-12877-6S161	HOSE ASSEMBLY	29	LW-16266-10-75	CLAMP	51
LW-12878-4S373	HOSE ASSEMBLY	27	LW-16266-25-25	CLAMP	55
LW-12879-6S262	HOSE ASSEMBLY	51	LW-16266-25-56	CLAMP	56
LW-12892	THRUST BUTTON	20	LW-16266-25-63	CLAMP	27
LW-12960	VALVE	25	LW-16266-25-63	CLAMP	51
LW-13215	OIL FILTER	47	LW-16475	SEAT	19
LW-13226	NUT	55	LW-16561	NIPPLE	29
LW-13227	ADAPTER	55	LW-16783-24	GAGE ASSEMBLY	33
LW-13323	SEAT	19	LW-18038	GASKET	27
LW-13389	BAFFLE ASSY	23	LW-18085	SPRING	7
LW-13790	SHAFT	20	LW-18638	LOCKPLATE	9
LW-13792	SEAL	7	LW-18661	SEAL	19
LW-13795	SHAFT	11	LW-18667	PIN	9
LW-13807	ADAPTER ASSY	31	LW-18737	HOSE	53
LW-13896	PLUG	3	LW-19096	GEAR RETAINER	55
LW-13908	CAMSHAFT	9	LW-19168	SUMP ASSEMBLY	35
LW-13926	ADAPTER	55	LW-19189	CABLE	59
LW-14021	SHAFT	3	LW-19200	COUNTERWEIGHT	9
LW-14078	PIN	15	LW-19210	CWT ASSY	9
LW-14260	SEAL	39	LW-19340	CAMSHAFT ASSY	9
LW-14445-10	VALVE ASSEMBLY	31	LW-25-0.63	BOLT	11
LW-14685-CT	ELBOW	27	LW-25-0.81	BOLT	31
LW-14820	RING	9	LW-25-0.94	BOLT	31
LW-14848-8S360	HOSE ASSEMBLY	27	LW-25-0.94	BOLT	39
LW-14995	SPRING	19	LW-25-0.94	BOLT.	51
LW-15550	GEROTOR PUMP	45	LW-25-1.00	BOLT	35
LW-15558	ROLLER	9	LW-25-1.00	BOLT	47

PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
LW-25-1.13	BOLT	13	MS29512-04	O-RING	29
LW-25-1.13	BOLT	35	MS29512-04	O-RING	55
LW-25-1.13	BOLT	39	MS29512-06	O-RING	5
LW-25-1.25	BOLT	31	MS29513-138	O-RING	31
LW-25-1.25	BOLT	35	MS35489-20X	GROMMET	23
LW-25-1.44	BOLT	39	MS9245-44	COTTER PIN	55
LW-25-1.50	BOLT	13	MS9321-12	WASHER	25
LW-25-1.88	BOLT	13	STD-8	WASHER	13
LW-25-2.00	BOLT	13	STD-8	WASHER	31
LW-25S1.50	BOLT	13	STD-8	WASHER	35
LW-25SS-0.75	BOLT	59	STD-8	WASHER	39
LW-31-0.94	BOLT	1	STD-8	WASHER	43
LW-31-0.94	BOLT	27	STD-8	WASHER	45
LW-31-0.94	BOLT	61	STD-8	WASHER	47
LW-31-1.16	BOLT	13	STD-8	WASHER	51
LW-31-1.16	BOLT	61	STD-19	DOWEL	3
LW-31-1.31	BOLT	49	STD-28	WASHER	31
LW-31-2.75	BOLT	13	STD-33	WASHER	13
LW-31H0.88	BOLT	1	STD-33	WASHER	25
LW-31H0.88	BOLT	11	STD-33	WASHER	27
LW-31SS-0.75	BOLT	27	STD-33	WASHER	33
LW-31SSH0.88	BOLT	25	STD-33	WASHER	55
LW-38-0.75	BOLT	27	STD-35	WASHER	1
LW-38-2.75	BOLT	25	STD-35	WASHER	3
LW-38-3.50	BOLT	25	STD-35	WASHER	13
MS16562-28	PIN	45	STD-35	WASHER	27
MS171526	PIN SPRING	7	STD-35	WASHER	39
MS20500-624	NUT	25	STD-35	WASHER	41
MS20822-4	ELBOW°	27	STD-35	WASHER	43
MS20822-4	ELBOW	55	STD-35	WASHER	49
MS-20822-4	ELBOW	37	STD-35	WASHER	61
MS20822-6	ELBOW	41	STD-82	SCREW	49
MS20822-6	ELBOW	51	STD-95	KEY	45
MS20823-6	ELBOW	29	STD-148	NIPPLE	49
MS20823-6D	ELBOW	17	STD-160	WASHER	13
MS20823-8	ELBOW	27	STD-160	WASHER	31
MS21042-3	NUT	27	STD-160	WASHER	35
MS28775-137	O-RING	45	STD-160	WASHER	39



PART NO.	PART NAME	PAGE NO.	PART NO.	PART NAME	PAGE NO.
STD-160	WASHER	43	STD-1171	INSERT	35
STD-160	WASHER	45	STD-1173	INSERT	35
STD-160	WASHER	47	STD-1211	PLUG	9
STD-160	WASHER	51	STD-1339	PLUG	5
STD-213	OIL SEAL	11	STD-1339	PLUG	39
STD-251	WASHER	31	STD-1339	PLUG	53
STD-251	WASHER	49	STD-1353	INSERT	17
STD-425	WASHER	27	STD-1410	NUT	3
STD-425	WASHER	51	STD-1410	NUT	41
STD-425	WASHER	53	STD-1410	NUT	43
STD-475	WASHER	3	STD-1410	NUT	55
STD-475	WASHER	13	STD-1410	NUT	61
STD-475	WASHER	27	STD-1411	NUT	13
STD-475	WASHER	41	STD-1411	NUT	19
STD-475	WASHER	43	STD-1411	NUT	35
STD-475	WASHER	49	STD-1411	NUT	43
STD-475	WASHER	55	STD-1411	NUT	45
STD-475	WASHER	61	STD-1411	NUT	47
STD-551	PLUG	35	STD-1411	NUT	59
STD-596	NUT	13	STD-1420	NUT	39
STD-596	NUT	33	STD-1650	BOLT	27
STD-670	LOCK NUT	29	STD-1737	RING	11
STD-670	LOCK NUT	51	STD-1774	PIN	11
STD-670	LOCKNUT	53	STD-1774	PIN	43
STD-678	WASHER	13	STD-1774	PIN	45
STD-678	WASHER	25	STD-1821	HOSE	23
STD-678	WASHER	27	STD-1856	SCREW	53
STD-678	WASHER	33	STD-1925	SCREW	23
STD-684	NIPPLE	23	STD-1925	SCREW	56
STD-692	SCREW	29	STD-2007	WASHER	55
STD-692	SCREW	51	STD-2044	NUT	59
STD-692	SCREW	53	STD-2048	HOSE	53
STD-714	COTTER PIN	39	STD-2079	NUT	55
STD-798	DOWEL	3	STD-2090	NUT	23
STD-860	SCREW	51	STD-2168	NUT	11
STD-860	SCREW	53	STD-2231	RING	9
STD-872	NUT	13	STD-2233	NUT	59
STD-1164	INSERT	35	STD-2238	NIPPLE	47

PART NO.	PART NAME	PAGE NO.
STD-2247	BOLT	9
STD-2248	SCREW	31
STD-2249	NUT	13

This page intentionally blank.